

Brandy Bullet Vibrator by JOYSTOYS PARIS

SKU : BRANDY-BULLET-VIBRATOR-BF2Y · Brand : JOYSTOYS PARIS

The Brandy Bullet Vibrator by JOYSTOYS PARIS is a compact mini vibrator designed to deliver intense stimulation in a discreet, easy-to-handle format. Its rounded body and soft-touch silicone texture ensure a pleasant feel against the skin, while its ergonomic shape makes it comfortable to hold for solo play or use with a partner.

Powered by a strong motor with multiple vibration modes, this bullet vibrator adapts to every mood, from gentle, gradual pulses to more intense sensations. Fully waterproof, it can be used in the shower or bath and is easy to clean after each use.

USB rechargeable, the Brandy Bullet Vibrator eliminates the need for disposable batteries and offers reliable battery life for regular use. Its elegant purple finish and polished packaging make it an eye-catching addition to any display, making it especially well-suited for intimate wellness retailers looking to offer a quality, accessible entry-to-mid range product.

Compact, quiet and versatile, this mini vibrator suits beginners and experienced users alike who want a simple, travel-friendly pleasure accessory.

Highlights

- Soft, skin-friendly silicone construction
- Waterproof design for shower or bath play
- Multiple vibration modes with varying intensities
- USB rechargeable, no disposable batteries needed
- Compact, discreet size that's easy to travel with
- Powerful yet whisper-quiet motor

Technical specifications

Material	Premium silicone
Product type	Mini bullet vibrator
Waterproof rating	Waterproof (safe for shower/bath use)
Power source	USB rechargeable
Vibration modes	Multiple vibration settings
Color	Purple

Box contents

- 1 x Brandy Bullet Vibrator
- 1 x USB charging cable
- 1 x Packaging box

Usage tips

For best results, use a water-based lubricant compatible with silicone toys to enhance glide and comfort. Start with the gentlest vibration mode and gradually increase intensity to suit your preference.

Care instructions

Clean the vibrator before and after each use with mild soap or a specialized toy cleaner, then rinse and dry thoroughly.

Avoid abrasive or alcohol-based cleaners, as they can damage the silicone surface. Store in a dry place away from direct light, ideally in an individual storage pouch.

Safety information

For adult use only. Check the product's waterproof seal before prolonged submersion. Avoid exposing to extreme temperatures. Keep out of reach of children.