

Havana Rabbit Vibrator by JOYSTOYS PARIS

SKU : HAVANA-VIBRATOR-X8SE · Brand : JOYSTOYS PARIS

The Havana vibrator by JOYSTOYS PARIS is a rabbit-style vibrator engineered for dual stimulation, pairing a curved shaft designed for G-spot pleasure with an ergonomic clitoral arm positioned for precise, consistent contact. Its body is fully covered in soft-touch, hypoallergenic silicone that feels smooth against the skin, available in a pastel lilac shade that fits seamlessly into any lingerie or intimate wellness collection.

Featuring multiple multi-speed vibration modes controlled through two simple touch buttons (power on/off and mode selection), this vibrator delivers a progressive experience, from gentle massage settings to more intense sensations. Its IPX7 waterproof rating allows use in the shower or bath and makes post-use cleaning significantly easier, a feature valued by both end users and retailers focused on product hygiene.

USB rechargeable, the Havana eliminates the need for disposable batteries and offers reliable battery life for regular use. Its ergonomic shape, comfortable grip, and clean design make it approachable for both experienced users and newcomers exploring dual stimulation for the first time. A versatile, quality item to add to any vibrator lineup for specialty stores, adult e-commerce sites, or lingerie corners.

Highlights

- Simultaneous dual G-spot and clitoral stimulation
- Soft-touch, hypoallergenic silicone
- IPX7 waterproof: safe for shower or bath use
- USB rechargeable, battery-free
- Multiple multi-speed vibration modes
- Simple two-button touch controls

Technical specifications

Product Type	Dual-stimulation rabbit vibrator
Material	Soft-touch silicone
Color	Pastel lilac
Waterproof Rating	IPX7 (water-resistant)
Power Source	USB rechargeable
Functions	Multi-vibration, multiple speeds and modes
Controls	2 touch buttons (power on/off, mode selection)

Box contents

- 1 Havana vibrator
- 1 USB charging cable

Usage tips

Apply a generous amount of water-based lubricant compatible with silicone before use for optimal comfort. Start with the gentlest intensity settings before gradually increasing power according to personal preference. Dry the product thoroughly before storage, paying special attention to the control buttons.

Care instructions

Clean the vibrator before and after each use with a specialized toy cleaner or warm soapy water, then rinse and dry thoroughly. Avoid harsh solvents or high-concentration alcohol, which can damage the silicone. Store the device in a storage pouch, away from dust and direct light, separately from other silicone accessories to prevent material reactions.

Safety information

This product is intended for intimate use by adults 18 years of age and older only. Check silicone compatibility with any lubricants used (water-based lubricants are recommended). Do not submerge the product beyond IPX7 waterproof specifications. Avoid exposure to extreme temperatures or sharp objects that could damage the silicone.