

Powerful Purple Silicone Wand Massager - 10 Vibration Modes

SKU : WAND-PUISSANT-JCW4 · Brand : JOYSTOYS PARIS

The Powerful Wand Massager from JOYSTOYS PARIS is a full-size wand vibrator engineered to deliver intense, versatile sensations for a wide range of users. Its rounded head and ergonomic handle, finished with a textured non-slip grip pattern, ensure a secure and comfortable hold whether it's used for full-body relaxation or targeted stimulation. Crafted from soft-touch, body-safe silicone, this wand offers 10 distinct vibration modes, controlled through three intuitive touch buttons on the handle, allowing users to fine-tune intensity and rhythm to suit their personal preferences. Its whisper-quiet motor ensures discreet operation, a feature highly valued by customers who prioritize privacy. Rated IPX7 waterproof, the wand can be used in the shower or bath and is easy to clean with water. It recharges conveniently via USB cable, eliminating the need for batteries and ensuring reliable everyday use. Packaged in polished, brand-consistent retail packaging from JOYSTOYS PARIS, with clearly listed technical details (model JW-200, dimensions, CE and RoHS certifications), this wand is a solid addition for shops and professional resellers looking to offer their customers a dependable, stylish, and high-performing wand massager.

Highlights

- 10 vibration modes for a fully customizable experience
- Whisper-quiet motor for discreet use
- IPX7 waterproof rating, safe for shower or bath use
- Soft-touch, body-safe silicone construction
- USB rechargeable, no batteries required
- Premium retail-ready packaging for resale

Technical specifications

Model	JW-200
Material	Body-safe silicone
Color	Purple
Total length	20.5 cm (8.07 in)
Handle diameter	3.5 cm (1.38 in)
Number of vibration modes	10
Waterproof rating	IPX7
Power source	USB rechargeable
Motor	Whisper-quiet
Certifications	CE, RoHS
Origin	Made in China

Box contents

- 1 JOYSTOYS PARIS Wand Massager
- 1 USB charging cable
- 1 retail packaging box with product information

Usage tips

Apply a water-based lubricant compatible with silicone for optimal glide. Select the desired vibration mode using the touch buttons on the handle and gradually adjust the intensity. Fully charge the device via the USB cable before first use.

Care instructions

Clean the wand with warm water and mild soap or a dedicated toy cleaner after each use, thanks to its IPX7 waterproof rating. Dry thoroughly before storing. Avoid harsh solvents and never submerge the charging port.

Safety information

Made from body-safe, phthalate-free silicone. Compliant with CE and RoHS standards. Do not submerge the charging port. Keep out of reach of children.